

軽量強化 赤い実〈イングリーズ〉

ダイアセラム



11-123-1-49370601
¥3,000
18cm長角皿
18.3×12.5×2.6



11-123-2-51080601
¥1,800
20cm皿 20.4×2.9



11-123-3-51070601
¥1,500
18cm皿 17.8×2.6



11-123-4-51060601
¥1,200
16cm皿 16×2



11-123-5-48050601
¥1,000
12cm皿 12.5×2.6



11-123-6-50604601
¥900
10cm皿 10×2



11-123-7-51180601
¥1,900
20cm深皿 20.4×4.1



11-123-8-51172601
¥1,800
19cm深皿 19×3.9



11-123-9-51170601
¥1,700
18cm深皿 17.9×4



11-123-10-51030601
¥1,500
16cm深皿 15.9×3.9



11-123-11-56071601
¥1,100
13cm深皿 12.8×3.6



11-123-12-51010601
¥1,100
14cm深皿 13.9×3.2



11-123-13-51050601
¥1,000
メタ12cm深皿 12.5×2.6



11-123-14-50040601
¥900
メタ9cm深皿 9.5×2.3



11-123-15-51252601
¥1,400
14cmボール 14.6×6-510cc



11-123-16-51251601
¥1,400
13.5cmボール 13.6×5.5-410cc



11-123-17-51253601
¥1,400
13.5cm切立ボール
13.7×5.9-420cc



11-123-18-51250601
¥1,400
13cmボール
12.7×5.3-350cc



11-123-19-54030601
¥1,300
11cm京茶碗
11.5×5.4-260cc



11-123-20-51497601
¥1,300
12cmボール
11.5×4.8-230cc



11-123-21-51240601
¥1,200
10cmボール
10.5×4.9-200cc



11-123-22-48340601
¥1,200
8cmスタックボール
8.3×4-120cc



11-124-1-49210601
¥1,200
11cm菊型深鉢
11×5.5-320cc



11-124-2-49220601
¥1,100
11cm菊型浅鉢
10.9×3.3



11-124-3-49180601
¥1,500
12cm六山鉢
12×5.8-300cc



11-124-4-49190601
¥1,400
11cm六山鉢
11.1×4.8-200cc



11-124-5-49420601
¥1,100
長湯呑
6.3×7.5-160cc



11-124-6-50481601
¥1,200
反湯呑
9.3×5.8-200cc



¥2,700
11-124-7-49500601 ¥1,500
ココット13.3×12×8.7-260cc
11-124-8-49090601 ¥1,200
蓋(小) 10.9×3.3



11-124-9-50505601
¥1,300
13cm耳付小鉢 12.8×11.3×4.2



11-124-10-48130601
¥1,400
スタック碗 8.3×6-200cc



11-124-11-51130601
¥1,500
マグカップ 7.3×7.3-200cc



11-124-12-51139601 ¥1,500
スタックカップ
7.3×7.6-200cc



11-124-13-48110601 ¥1,500
スタック兼用碗
8.3×6-200cc



11-124-14-48120601 ¥1,600
スタック両手碗
8.3×6-200cc



11-124-15-50101601 ¥1,600
オープンハンドル
8.6×6.6-190cc



¥2,300
11-124-16-49100601
¥1,400
丸深鉢 10.6×6.7-280cc
11-124-17-49171601
¥900
かぶせ蓋(大) 11×2



¥2,100
11-124-18-49110601
¥1,200
丸小鉢 10.6×6-220cc
11-124-19-49171601
¥900
かぶせ蓋(大) 11×2



¥3,100
11-124-20-49140601
¥1,300 茶碗蒸 7.4×6.6-170cc
11-124-21-49172601
¥900 かぶせ蓋(小) 8.4×1.7
11-124-22-50604601
¥900 受皿 10×2



11-124-23-49240601
¥1,800
10cm角鉢 9.8×3.6



11-124-24-49230601
¥2,000
9cm隅切角小鉢 9.4×4.9



¥3,200
11-124-25-49010601
¥1,800
ライス碗(大)
14.8×9.8-400cc
11-124-26-49070601
¥1,400 蓋(大)
13.1×3.6



¥2,800
11-124-27-49020601
¥1,500
ライス碗(中)
13.4×7-300cc
11-124-28-49090601
¥1,300 蓋(中)
12.2×3.3



¥2,700
11-124-29-49030601
¥1,500
ライス碗(小)
12.2×5.9-200cc
11-124-30-49090601
¥1,200 蓋(小)
10.9×3.3



¥3,200
11-124-31-49040601
¥1,800
多用碗(大)
14.8×6.1-300cc
11-124-32-49070601
¥1,400 蓋(大)
13.1×3.6



¥2,800
11-124-33-49050601
¥1,500
多用碗(中)
13.6×6.1-300cc
11-124-34-49090601
¥1,300 蓋(中)
12.2×3.3



¥2,700
11-124-35-49060601
¥1,500
多用碗(小)
12.2×5.9-250cc
11-124-36-49090601
¥1,200 蓋(小)
10.9×3.3