



11-139-1-86180071 ¥1,200
24cm深皿 黒耀 24.4×5



11-139-2-86170071 ¥800
21cm深皿 黒耀 21.5×4



11-139-3-86010071 ¥600
14cm深皿 黒耀 14.7×3.8



11-139-4-86043071 ¥500
11cm深皿 黒耀 11×3.4



11-139-5-40040071 ¥500
10cm深皿 黒耀 10×2.5



11-139-6-86042071 ¥400
8cm深皿 黒耀 8.3×2.3



11-139-7-86030071 ¥700
17cm煮物鉢 黒耀 16.7×5.2



11-139-8-86350071 ¥1,100
16cm深鉢 黒耀 16.5×6.6・810cc



11-139-9-86345071 ¥800
14cm深鉢 黒耀 14.2×6・650cc



11-139-10-86338071 ¥700
11cm深鉢 黒耀 11×5.9・280cc



11-139-11-86342071 ¥700
13cm浅鉢 黒耀 13×4.5・290cc



11-139-12-86337071 ¥700
11cm浅鉢 黒耀 11.2×4.2・200cc



11-139-13-86333071 ¥600
9cm浅鉢 黒耀 9.4×3.8・120cc



11-139-14-86270071 ¥1,400
22cm丼 黒耀 21.4×8.9・1,400cc



11-139-15-86268071 ¥1,300
21cm丼 黒耀 20.5×8.6・1,300cc



11-139-16-86265071 ¥1,100
20cm丼 黒耀 19.9×7.9・1,000cc



11-139-17-86263071 ¥1,700
19cm深丼 黒耀 18.8×10.2・1,350cc



11-139-18-86260071 ¥1,500
18cm深丼 黒耀 18×9.3・1,150cc



11-139-19-86250071 ¥1,100
16cm深丼 黒耀 16.1×8.7・780cc



11-139-20-86248071 ¥1,000
15cm深丼 黒耀 15×8.3・650cc



11-139-21-86245071 ¥900
14cm深丼 黒耀 13.6×7.8・500cc



11-139-22-86238071 ¥700
13cm深丼 黒耀 12.7×6.3・310cc



11-139-23-86280071 ¥2,000
24cm麵鉢 黒耀 24×6.8・1,500cc



11-139-24-86275071 ¥1,600
23cm麵鉢 黒耀 22.3×6.9・1,200cc



11-140-1-86763071 ¥1,600
19cm玉丼 黒耀 19×9.8・1,350cc



11-140-2-86760071 ¥1,500
18cm玉丼 黒耀 18.3×9.1・1,200cc



11-140-3-86755071 ¥1,000
16cm玉丼 黒耀 16.2×8.2・800cc



11-140-4-86745071 ¥800
14cm玉丼 黒耀 14.4×7.6・570cc



11-140-5-86740071 ¥700
13cm玉丼 黒耀 12.8×7・470cc



11-140-6-86736071 ¥700
11cm玉丼 黒耀 11×5.8・320cc



11-140-7-86597071 ¥600
9cm深小鉢 黒耀 9.4×6.2・190cc



11-140-8-21340071 ¥600
8cmソバチョコ 黒耀 8.2×6.2
11-140-9-21370071 ¥500
8cm薬味皿 黒耀 8.5×1.6



11-140-10-21023071 ¥1,000
20cm三連皿 黒耀 20×7×3.2



11-140-11-21022071 ¥800
14cm二連皿 黒耀 13.7×7×3.2



11-140-12-864890071 ¥600
湯呑 黒耀 7.7×8・200cc
※コースターは価格に含まれておりません。



11-140-13-86581071 ¥800
フリーカップ 黒耀 8×11.4・280cc
※コースターは価格に含まれておりません。



11-140-14-21370071 ¥500
8cm薬味皿 黒耀 8.5×1.6



11-140-15-86130071 ¥700
反マグ 黒耀 8.8×8.8・300cc
11-140-16-99821006 ¥200
9.5cm丸型コルクコースター 9.5×0.6